


Installation manual



YC8001-MH-90




Thank you for shopping with us!

We encourage you to take a few minutes to go through this booklet. It contains important information on installation and care tips to keep your furniture looking as good as new.


Attention

 Prohibited	Cleaning agent with (acidic) mark	Bathroom cabinet may change color
	Cleaning agent with (alkaline) mark	
 Must be executed	1.Many cleaners contain abrasives and chemicals and cannot be used to clean stainless steel, enamel, plating or plastic products. These surfaces must be cleaned with a mild detergent or make-up solution, the residual wash is washed, and then wiped dry with a clean soft cloth	
	2.Please keep a good ventilation in the bathroom. you can dry and wet che separation. usually, keep opening the window and opening the door.	
	3.The bathroom cabinets are subjected to strict moisture-proof treatment, When using, the bathroom cabinets are not allowed to be watered or splashed. Good moisture resistance can ensure good use at high relative humidity, so please avoid the bathroom is too humid, in case of water, it should be dried in time.	
	4.Maintenance of the door panel: Regularly clean and wipe with a soft cloth. The cold water vapor after bathing should be dried with a dry cloth to keep the door panel dry.	
	5.Do not sit, lean, lean on, or step on the washbasin cabinet during daily use	





















Recommended tools




Components



Hardware


				
A=24 PCS	B=52 PCS	C=52 PCS	E=60 PCS	F=12 PCS
				
G=22 PCS	H=2 PCS	K1=3 PCS	M=2 PCS	N=2 PCS
				
O=4 PCS	R=2 PCS	S=2 PCS	T=2 PCS	U=5 PCS
				
V=4 PCS	W=1 PCS	X=12 PCS	Y=28 PCS	Z=3 PCS

Step 1




Notes: Screw installation depth as shown


Step 2




Step 3




first step




second step




third step



Step 4




Step 5




X*2

Step 6




G*3

Step 7




G*2

Step 8




B*11


Step 9




Step 10




Step 11




Step 12




Step 13





Step 14




Step 15




Step 16




Step 17




Step 18





Step 19





Step 20





Step 21





Step 22






Step 23




Step 24




C*52




Step 29



Step 30



OK



THANKS FOR WATCHING

Your feedback is invaluable to us and we would love to hear about your experience. Please take the time to leave us a review.